

481

483

SERVICE MANUAL

Notes on safety

- The machine must only be operated in full knowledge of the instruction book and by persons with appropriate training.
- Before commissioning the machine also read the motor manufacturer's safety notes and instruction manual.
- The machine must only be used for the purpose intended. It must not be operated without the safety devices it is equipped with; all valid safety regulations must be adhered to.
- When gauge parts are exchanged (e.g. needle, presser foot, needle plate, feed dog and bobbin), during threading, when the workplace is left, and during service work, the machine must be isolated from the mains by switching off the main switch or disconnecting the mains plug.
- On mechanically operated clutch motors without start inhibitor it is necessary to wait until the motor has stopped.
- Daily servicing work must only be carried out by persons with appropriate training.
- Repairs and special maintenance work must only be carried out by trained technicians or persons with appropriate training.
- For service or repair work on pneumatic systems the machine must be disconnected from the compressed air supply system. The only exceptions to this are adjustments and function checks carried out by appropriately trained technicians.
- Work on the electrical equipment must only be carried out by electrical engineers or other appropriately trained technicians.
- It is not permitted to work on live parts. For exceptions please see the EN 50 110 regulations.
- Conversions or changes to the machine must only be made on adherence to all safety regulations.
- For repairs, only replacement parts approved by us must be used.
- The sewing head must not be operated until it is ascertained that the whole sewing unit corresponds to EC-regulations.

Tools, gauges and other adjustment aids

- 1 set of screwdrivers with blades from 2 to 10 mm wide
- 1 set of spanners from 7 to 14 mm wide
- 1 set of hexagonal allen keys ranging from 1.5 to 6 mm
- 1 wrench, 22 mm wide
- 1 metal ruler (part No. 08-880 218-00)
- 1 cylindrical pin (5 mm in diameter), part No. 13-030 341-05
- 1 adjustment gauge, part No. 61-111 642-19

Notes on the service manual

All the adjustments in this service manual apply for a completely mounted machine. No mention is made of the machine covers that occasionally have to be screwed off and back on for testing and adjustment purposes.

The screws and nuts in brackets () are for the attachment of machine parts that must be loosened before the adjustments and tightened up again afterwards.

Abbreviations

t.d.c = top dead center

b.d.c. = bottom dead center


Checking and adjustment aid

By inserting the cylindrical pin in one of the adjustment holes 1 to 6 it is possible to fix the required needle bar positions very precisely.

Turn the handwheel until the needle bar is roughly in the required position.

Insert the 5 mm thick cylindrical pin in the specified adjustment hole and press against it.

Turn the handwheel slightly to and fro until the cylindrical pin engages in the crank recess behind the bearing plate, thus blocking the machine.



Adjustment hole 1 = 0.6 mm past top dead center of the needle bar (0.6 past t.d.c.).

Adjustment hole 3 = 0.6 mm past the bottom dead center of the needle bar (0.6 past b.d.c.).

Adjustment hole 4 = 1.8 mm past the bottom dead center of the needle bar (needle rise position).


Adjustment hole 5 = top dead center of the needle bar (t.d.c. N).

Adjustment hole 6 = 4 mm past bottom dead center of needle bar (4 past b.d.c.).

Preliminary adjustment of needle height

Requirement

With the needle bar at b.d.c. there must be a clearance of **16.5 mm** between needle holder and needle plate.




- Move needle bar 1 (screw 2) according to the requirement. Make sure that, when looking in the feed direction, the needle retaining screw points to the right.

2 Zeroing the feed motion


Requirement

The feed dog must not move when turning the handwheel with the stitch length set at "0".

2.1 Zeroing procedure with the gearbox closed




- Raise the presser foot and set the stitch length control lever 1 at its lowest position.
- Turn eccentric bushing 2 (screw 3) so that mark 4 is roughly at the bottom and the edge of the milled surface is at an angle of 45° to the machine front (for final adjustment see section 23).
- Insert an allen key in one of the holes in collar 5. Use the allen key to hold the shaft in position.
- Rotate the handwheel and at the same time turn shaft 6 (screw 7) with the allen key according to the requirement. Remember that in the PFAFF 483 there must be a clearance of 8 mm between the bearing bush and actuating crank 8.



- Raise the presser foot and set the stitch length control lever **1** at its lowest position.
- Turn eccentric bushing **2** (screw **3**) so that mark **4** is roughly at the bottom and the edge of the milled surface is at an angle of 45° to the machine front (for final adjustment see section 23).
- Turn crank **5** (screw **6**) according to the requirement.

Requirement:

With the stitch length control set at "0" the needle bar should make no feed motion when the handwheel is turned.



- Adjust needle feed regulating crank **1** (screw **2**) according to the requirement.

Adjustment aid:

Insert a screwdriver in needle feed driving crank **3** - it must remain still when the handwheel is turned.


Requirement

With the stitch length set at "0"

the feed dog should be at t.d.c. when the needle bar is at a position 0.6 mm past b.d.c (cylindrical pin in hole "3"; for **PFAFF 481**)

or 0.6 mm past t.d.c (cylindrical pin in hole "1"; for **PFAFF 483**).

In this position, the notch in feed lifting eccentric **1** should be positioned perpendicularly below the center of the shaft.




- Turn feed lifting eccentric **1** (screws **2**) according to the requirement.

Requirement

With the stitch length set at "0" and the needle bar at a position 0.6 mm past b.d.c (cylindrical pin in hole "3", for **PFAFF 481**) and 0.6 past t.d.c. (cylindrical pin in hole "1"; for **PFAFF 483**)


1. the feed dog must be positioned in the middle of the needle plate slots when looked at from the side as well as in feeding direction.
2. the feed dog must be at its top point of reversal and must contact the gauge throughout its entire length.



- Move feed bar 1 (screw 2) according to requirement 1.
- Lower the presser foot until it rests on the gauge.
- Turn eccentric 3 (screw 4) and eccentric 5 (screw 6) according to requirement 2.

Requirement


With the longest stitch length set and
 the needle bar at 0.6 mm past b.d.c. (cylindrical pin in hole "3"; for **PFAFF 481**)
 the needle bar at 0.6 mm past t.d.c. (cylindrical pin in hole "1"; for **PFAFF 483**)
 the feed dog should not move when the reverse-feed control is moved up and down.



- Turn feed driving eccentric **1** (screws **2**) according to the requirement. Make sure that the notch in the feed driving eccentric is visible.

Requirement

Both the needle bar and the feed dog should remain motionless when reverse-feed control **3** is moved up and down with the machine set for its longest stitch and the needle bar set 0.6 mm past its b.d.c. (cylindrical pin in hole "3").



- Turn feed driving eccentric **1** (screws **2**) according to the requirement making sure that the notch in feed driving eccentric **1** points to the front.

Adjustment aid:


For easier checking insert a screwdriver in driving crank **4**.

Requirement


The needle must penetrate the needle hole right in the center.

8.1

For PFAFF 481




- Set the stitch length at "0" and position the needle right above the needle hole.
- Loosen screws 1 and 2.
- Position needle bar frame 3 both lengthwise and crosswise of the sewing direction according to the requirement and tighten screw 1.
- Turn the handwheel a few turns to ensure that the needle bar is not under stress in the needle bar frame and tighten screw 2.



- Position the needle bar just above the needle hole.
- Loosen screws 1, 2 and 3.
- Position needle bar frame 4 both lengthwise and crosswise of the sewing direction according to the requirement and tighten screw 2 just lightly and screw 3 firmly.
- Turn screw 1 to move the guide pin behind this screw towards the eye of the needle bar frame and tighten it.
- Turn the handwheel a few turns to ensure that the needle bar is not under stress in the needle bar frame and tighten screw 2.

Requirement

1. The notch in bearing **3** (see arrow) must be visible from below.
There must be a slight but still noticeable play between gears **5** and **7**.
2. With the hook set lightly against spin disc **4** and the hook point opposite the center line of the needle, there must be clearance of **less than 0.1 mm** between the hook point and the clearance cut of the needle.
3. Gear **5** must be flush with gear **7**.




- Loosen screws **1** and **2**.
- Turn bearing **3** according to requirement 1.
- Set the hook lightly against spin disc **4**, shift bearing **3** - without turning it - according to requirement 2 and tighten screws **1** and **2**.
- Position gear **5** (screws **6**) according to requirement 3.

Needle rise, final adjustment of needle bar height and bobbin case positioning finger

Requirement

With the stitch length set at "0" and the needle bar at a position **1.8 mm** past b.d.c. (cylindrical pin in hole "4")

1. the hook point must be opposite the center line of the needle and the top edge of the needle eye must be **0.8 mm** below the bottom edge of the sewing hook.
2. there must be a clearance of **0.5 mm** between the lug of positioning finger **3** and the inside edge of the positioning slot.




- Adjust the hook (screws **1**) without shifting it and the needle bar (screws **2**) without turning it according to requirement 1.
- Set lug of positioning finger **3** into the slot in the bobbin case base; adjust and fix it according to requirement 2.

Requirement**1. Small hook (481 and 483)**

At the left point of reversal of bobbin case opener **3** the bobbin case opener finger must be roughly on one level with the lug of bobbin case base **4**.

2. Large hook (481G and 483G)

At the left point of reversal of bobbin case opener **3** the top edge of the bobbin case opener finger must be **0.5 mm** above the bottom edge of bobbin case cam **5**.



- Turn bobbin case base **1** (screw **2**) according to requirements 1 and 2.

Requirement**1. Small hook (481 and 483)**


With bobbin case opener **3** in its left point of reversal there must be a clearance of approx. **0.8 mm** between the front edge of the bobbin case opener finger and the edge of bobbin case base **6**.

2. Large hook (481 and 483)

At the left point of reversal of bobbin case opener **3** the front edge of the bobbin case opener finger must be roughly **0.6 mm** behind the front edge of bobbin case cam **7**.

3. Large hook and small hook (481 and 483)


At the left point of reversal of bobbin case opener **3** there must be a clearance of roughly **0.3 mm** between bobbin case base **6** and positioning finger **8** and stop screw **1** must be in contact with stop pin **5**.



- Loosen screw **1**. Then loosen screw **2** so that bobbin case opener **3** is still held in position.
- Adjust bobbin case opener **3** according to requirements 1 and 2.
- Turn bobbin case opener **3** according to requirement 1 and tighten screw **2**.
- Set fixing collar **4** against bobbin case opener **3** and stop pin **5** and tighten screw **1**.

Requirement

In needle bar position **1.8 mm** past b.d.c. (cylindrical pin in hole "4") bobbin case opener finger must be at its **right** point of reversal.



- Adjust bobbin case opener eccentric **1** (screws **2**) according to the requirement.


Adjustment aid:

To facilitate checking insert a screwdriver in the slot of bobbin case opener **3**.

Requirement

With presser bar lifter **1** raised there must be a clearance of **5 mm** between presser foot and needle plate.


Note: When the presser foot is raised to its top position upon actuating the knee lever fully or by means of the automatic presser foot lift -910/.. there must not be any contact between presser foot bush **6** and presser foot.



- Lower presser bar lifter **1** to rest the presser foot on the needle plate.
- Turn out regulating screw **2** to lower the pressure on the presser bar.
- Place the 5-mm-thick blade of the gauge under the presser foot fulcrum.
- Loosen screw **3** and raise presser bar lifter **1**.
- Let the needle penetrate the needle hole of the presser foot and adjust the presser foot so that the needle is centered in the needle hole of the presser foot.
- Press lifting bracket **4** downwards onto the raised lifting lever **5** and tighten screw **3**.
- Remove the gauge and lower the presser foot onto the needle plate.

Requirement


With the machine set for its longest stitch, both the feed dog and the needle must make feed strokes of the same length when the handwheel is turned.



- Shift hinge stud **1** (nut **2**) to adjust the feed stroke of the needle feed.
- Check whether the needle feed is still zeroed properly (see Section 3) and adjust, if necessary.

Requirement


When presser bar lifter 1 is raised both tension discs must be at least **0.5 mm** apart.



- Adjust tension release lever 2 (screw 3) according to the requirement.
- Lower the presser foot onto the needle plate. Now the tension must be fully activated.

Requirement

1. Thread check spring **3** must have moved by its full stroke by the time the point of the needle enters the material (stroke approx. **7 mm**).
2. Thread regulator **4** must be fixed in the elongated hole so that thread check spring **3** moves by 1 mm by the time the hook has widened the thread loop to its maximum.




- Turn thread tension **1** (screws **2**) according to requirement 1.
- Shift thread regulator **4** (screws **5**) according to requirement 2.

Note:

The stroke of thread check spring **3** and the position of thread regulator **4** are dependent on the type of thread and material used and should be adjusted according to the appearance of the seam.

Requirement


When at rest, knee lever connecting rod 2 must be at right angles with the bedplate.



- Raise the presser foot by means of the presser bar lifter.
- Push the knee lever joint on knee lever shaft 1 and let the connecting rod 2 engage in the joint.
- Turn stop screw 3 (nut 4) according to the requirement.

Requirement

When the presser foot is resting on the needle plate, there must be a clearance of **1.3 mm** between lifting lever **3** and lifting piece **4**.




- Position the needle at its b.d.c. and let the presser foot down on the needle plate.
- Turn crank **1** (screws **2**) according to the requirement. Make sure the vertical knee lever shaft has no end play.

Requirement

When the knee lever is pushed by the full amount of its travel, there must be a clearance as indicated in the table below between presser foot and needle plate and the presser bar lifter should drop by its own weight.

Version A and subclass -731/...: **7 mm**


Versions B and C: **9 mm**




- Turn stop screw **1** (nut **2**) out a few turns.
- Raise the presser bar lifter.
- Place the 7-mm-thick or the 9-mm-thick blade of the gauge under the presser foot and lower the presser bar lifter.
- Push the knee lever until a noticeable resistance is felt; the presser foot must not yet lift off the gauge. First turn in stop screw **1** (nut **2**) fully, then back out by half a turn.

Requirement

When the bobbin winder is engaged, the winder spindle should be driven reliably; when the bobbin winder is disengaged, however, drive wheel **1** must not contact friction wheel **5**. The bobbin winder should stop automatically when the thread wound on the bobbin has reached a point **about 1.0 mm** below the bobbin rim.




- Switch on the bobbin winder and adjust drive wheel **1** (screw **2**) according to the requirement.
- Place a bobbin on the winder spindle, thread the machine for bobbin winding and switch on the bobbin winder.
- To adjust the amount of thread wound shift regulating stud **3** (screw **4**) according to the requirement.



- Loosen screw **1** (accessible through the assembly hole) or turn it out according to the limit to be set.
- Set stitch length control lever **2** at the desired maximum stitch length.
- Set limiting angle **3** from above against control lever **2** and fix it (in the desired position) by tightening screw **1** in either the lower or the upper hole.

Requirement


When the stitch length is set at "3" the forwards feed must match the reverse feed.



- Turn bush 1 (screw 2) in accordance with the requirement. Make sure that the eccentricity of bush 1 points downwards.

Requirement

Proper feeding of the material must be ensured even at top sewing speed. There must
Contents



- Turn screw 1 according to the requirement.

Contents

	Checking and adjustment aid	3
1	Preliminary adjustment of the needle height	4
2	Zeroing the feed motion	5-6
3	Zeroing the needle feed motion (not applicable to PFAFF 483)	7
4	Feed lifting motion	8
5	Feed dog height	9
6	Feed driving motion	10
7	Timing the needle feed motion (not applicable to PFAFF 483)	11
8	Centering the needle in the needle hole	12-13
9	Eccentric hook shaft bearing and hook-to-needle clearance	14
10	Needle rise, final adjustment of needle height and bobbin case positioning finger ..	15
11	Vertical position of bobbin case opener	16
12	Position of bobbin case opener	17
13	Timing the bobbin case opener	18
14	Clearance between presser foot and needle plate	19
15	Eliminating feed differences (not applicable to PFAFF 483)	20
16	Tension release mechanism	21
17	Thread check spring and thread regulator	22
18	Knee lever resting position	23
19	Knee lever play	24
20	Adjusting the knee lever motion	25
21	Bobbin winder	26
22	Limiting the stitch length	27
23	Matching forwards and reverse stitch lengths	28
24	Presser foot pressure	29

[illegible]



Europäische Union
Wachstum durch Innovation – EFRE



PFAFF Industriesysteme und Maschinen AG

Hans-Geiger-Str. 12 - IG Nord
D-67661 Kaiserslautern

Phone: +49-631 200-0
Fax: +49-631 17202
E-mail: info@pfaff-industrial.com

Hotlines:

Technical service:	+49-175/2243-101
Application consultancy:	+49-175/2243-102
Spare-parts hotline:	+49-175/2243-103